


PRODUCT MANUAL

LUXTREME SL100



Our Luxtreme SL line of spotlights offer extraordinary beam distance and close range flood pattern in an ergonomic and rugged design.


LIGHT MODES

MODES	LUMENS	HOURS	METERS
LEP	280	6H 15M	1600
WHITE C.O.B.	500	13H 40M	42
RED C.O.B.	30	12	6
LEP + WHITE C.O.B.	525	10H 16M	1496


CONTINUOUS RUN WITH 12V ADAPTOR

FIRST USE

Remove battery spacer before operation! This unit uses a battery spacer during shipping. Remove before operation.




To remove the battery, unlatch the battery cover. After removing the spacer, insert the battery positive (+) side first.



OPERATION

Rotate the Mode Select Dial to cycle through light modes: **Off** > **Red COB** > **White COB** > **Spot**

Press the trigger button to turn the unit **ON**. Press again to turn **OFF**.




Smart Power Control seamlessly transitions through light modes.

POWER INDICATOR

This product uses 4 LED lights just above the Mode Select Dial.


- - **100% battery:** 3 green, 1 red
 - **75% battery:** 2 green, 1 red
 - **50% battery:** 1 green, 1 red
 - **25% battery:** 1 red



Press the trigger button while Mode Select Dial is in the **Off** position to show battery life.

CHARGING

Use the included charging cable to recharge the Luxtreme SL. The last indicator light will flash when the unit is charging. When charging is complete, all indicators will light continuously.



BELT CLIP

The Belt Clip is designed so that it can be mounted on either side of the base. Simply screw the Belt Clip in the desired position.

